

Rokk Mount Installation and Information Guide

Optional with your ROCKFLEET



1x Rokk Mount



4x White Plastic Washers (1.5mm)



4x Small Metal Washers



4x Stainless Machine Screws (M5 10mm)



4x Stainless Machine Screws

Fitting instructions

- 1 Fit your ROCKFLEET to the Rokk mount by attaching it to the top half first by using the stainless machine screws provided within the box;
- 2 Place a small metal washer between the M5 10 machine screw and the top half of the Rokk mount;
- 3 Then, place a white plastic washer between the top half of the Rokk mount and the ROCKFLEET unit!
- 4 With the ROCKFLEET fitted to the top half of the Rokk mount, place it onto a rail / pole / bar;
- 5 Then, lining up the bottom plate underneath the rail / pole / bar;
- 6 Secure the bottom half of the Rokk mount to the top half using the provided machine screws
- 7 Make sure all machine screws are tightened at the correct torque and the ROCKFLEET does not move!



Maximum screw torque limit - 6 N.m

Maximum Bend Radius = 6 x outer diameter

Red & Black Cable Cores



Red Core = +ve

Black Core = -ve

Power Supply Required



Attach the cable to a fused (2A) 8-32v DC supply

For further enquiries on how to install your RockFLEET, please contact us:

0800 SAT COM | info@pivotel.co.nz